

Wild Oasis



13 Ounce — Shelter



Setting Up Your Wild Oasis Shelter

Choose a campsite away from low hanging branches, and clear site of sharp objects such as sticks or rocks. Look for a site on a small rise where water will drain away from the shelter.

Setting up the **Wild Oasis** is tricky the first few times. So practice well before heading into the backcountry.

1. Insert the extender loops* into each of the guyline tie outs.
2. Lay out Oasis with rear pointing into the wind and stake out the two front corners of Oasis (either side of the vestibule).
3. Insert a stake through rear loop, square the rear of the cape with the front and stake into the ground.
4. Set your hiking pole length to **45 inches** (42 inches if not using the extenders).
5. Insert end tip of hiking pole into grommet in harness, and place handle end of pole on ground.
6. Pull out front guyline and stake. Adjust guyline tension, and position of pole as needed. Angle the pole forward with the bottom placed in the vestibule for extra sleeping space.
7. Pull out the two rear corners and stake.
8. Insert the webbing loop at the bottom end of the vestibule in to the hook that slides along the front guyline to secure the vestibule.

Allow a half hour for the Wild Oasis material to relax then re-tension as needed.

*Make 5 extender loops 6 inches in length from the extra thin guylines provided. Cut the line in 5 pieces 16 inches in length. Tie the ends together to form a loop. This loops allow you to raise the height of the shelter for additional ventilation. Use the remaining cord for the front guyline.

Seam Sealing

Before using your **Wild Oasis**, seal exposed outside seams with a Silicone based seam sealer. If you purchased SilNet™, follow the package instructions. (You will be able to seal the entire shelter with 1 tube.) To make your own sealer, follow the note below:

Hang or lay your cape out flat and cure for at least 12 hours after sealing.

Homemade silicone seam sealer:

To make your own seam sealer, check out the seam sealing page on our website:

<http://www.sixmoondesigns.com/support/seam.asp>

Safety Notes

DO NOT expose shelter to open flame from a fire, or stove.
DO NOT cook inside shelter.

Price:

Warranty

The Six Moon Designs gear is designed for a long service life. We have a lifetime warranty on workmanship. Since no gear is completely indestructible our warranty does not cover the following conditions:

- Normal wear and tear associated with usage.
- Damage resulting from abuse.
- Degradation of the materials by long term UV exposure.
- Exhaustion of zippers.
- Alteration of the gear from its original form.

Should you need to return the product for warranty or repair, contact us at **store@sixmoondesigns.com** for a return authorization number. We will inspect the gear to determine if defective. At which time we will either repair or replace free of charge. Service or repair of items not covered under warranty will be done at nominal charge.